



# Moboscan DTC Definition Update Procedure


1. Install the “DTC Definition Update Tool” first, it can be downloaded from our web site [www.innologic.com.hk](http://www.innologic.com.hk) or found in Software CD accomplished with the scanner package




- 2 · Open the tool by double click the file “DTC\_Definition\_Update.exe”




- 3 · Select product in Setup1, for example select Moboscan 8500




4. Select the “COM” port for connecting scanner. If you are not sure which USB serial port is available, you can go to “device manager” to search any ready port. (e.g. under device manager, you see “USB serial port (COM3), then you can select “COM3” for connecting scanner)







5. Power up the scanner with a 9V battery
6. Connect the scanner to the PC or notebook with the USB cable provided.
7. Click “Open” button in box “Setup2:Open COM”




- If open failed, there will be “Open COM failed” message displayed. That means the chosen USB serial port is not probably installed.




- Click “Read Flash” button in “Setup3:Open file”. The Tool will open the DTC definition file. Some figures are shown in “Tool information’ box and “DTC information” box



10. Turn on the scanner and you see the “Logo” screen



11. For Moboscan 8500, press the “UP arrow” key and hold for a few second  
For Moboscan 8550 and 8800, press “Y” key to main menu, select option “DTC update” function in main menu
12. Message “Download.....please wait” will be displayed on scanner
13. Click “Start” button in setup4:Download. Then download bar will start increasing from 0% to 100% (It may take 5 to 10 min)



14. “Update Complete” will be shown on both the update tool and scanner

